

TOPIT

Assembly instruction

Mounted on drawer sides.



1.



2. Place the frame on the drawer sides.



3. Attach the frame on the drawer front using 4 screws. 2 screws on each side.



4. Insert bins, lid and dividers.